Range and Resolution

760 to 0 torr absolute

1 torr resolution

Consult factory or see cecomp.com for models with higher resolution and accuracy, and additional features

Accuracy

Accuracy includes linearity, hysteresis, repeatability $\pm 0.25\%$ FS ± 1 LSD, (approx. ± 3 torr) Accuracy: Sensor hysteresis: ±0.015% FS, included in accuracy Sensor repeatability: ±0.01% FS, included in accuracy

3 readings per second nominal display update rate

3 digit LCD, 0.5" H digits

BL: LED display backlight on when gauge is on

Calibration

Front calibration potentiometers

Non-interactive zero and span

±10% range

Housing

NEMA 2 gray coated extruded aluminum case, ABS/ polycarbonate bezel, front and rear gaskets, polycarbonate label,

Weight

Approximately 9 ounces, shipping weight 1 pound

Connection and Material

1/4" NPT male fitting, 316L stainless steel All wetted parts are 316L stainless steel

Overpressure, Burst

2 X pressure range (approx. 30 psig)

4 X sensor burst pressure rating (approx. 60 psig)

Environmental Temperatures

-40 to 203°F (-40 to 95°C) Storage temperature: -4 to 180°F (-20 to 82°C) Operating temperature: Sensor compensated range: 32 to 158°F (0 to 70°C)

ARM760B Battery Powered

Batteries and Battery Life

Two AA alkaline included

ARM760B: 2500 hours (approximately) ARM760BBL: 180 hours (approximately) Low battery indication on display

Controls

Front button turns gauge on/off, starts auto shutoff timer **Auto Shutoff**

Quick Link: cecomp.com/arm

Factory set to 5, 10, 30 minutes, or -ON for on/off only

ARM760AD Low Voltage Powered

Controls

Front button turns gauge on/off

Electrical Connection

6 foot long, 2-conductor cable with Gauge:

female 3.5 mm socket

6 foot long, 2-conductor cable with Power supply:

male 3.5 mm plug


9-32 VDC or 8-24 VAC 50/60 Hz

Includes 120VAC/12VDC wall mount power supply

Power Consumption

ARM760AD: 5 mA (approximately) ARM760ADBL: 75 mA (approximately)





- Monitor Vacuum Systems and Pumps
- Replace Mercury Manometers
- Vacuum Packaging Machinery
- ±0.25% Test Gauge Accuracy
- 316 Stainless Steel Wetted Parts
- 760 to 0 Torr Absolute
- Battery or Externally Powered Versions





Туре
Battery powered
Battery powered, backlit display
Low voltage powered
Low voltage powered, backlit display

Time —Battery powered model auto shutoff time (factory configured)		
5	5 minutes. Default if not specified.	
10	10 minutes	
30	30 minutes	
ON	No auto shutoff. On/off via front button.	
Ontions—add to end of model number. Factory installed		

only. See cecomp.com/accessories for details.

PM	Panel mount, 4.1" x 4.1"	
MC	Metal front cover instead of plastic	
CS	Case bottom stiffener plate	
CC	Moisture resistant circuit board conformal coating	
TP	Top port, gauge port on top of case	
SM	Surface mount plate. Battery powered only.	
C-libti C-st C-sti		

Calibration Cert. Option—add to end of model number NIST traceability documentation, 5 points and date

Top gauge port. Primarily used with tire pressure applications. Not available with NEMA



Accessories-order separately

TP

High visibility orange rubber boot protects gauge for portable applications. Not available with NEMA 4X models.



SCR14SS

Filter screen fitting keeps debris out of gauge sensor. For food vacuum packaging applications. 303SS body, 100 micron 304SS screen.



CON14SS

Quick connector to install or remove gauge without tools, 304 stainless steel, urethane seal,









ARM760AD



Precautions

- Read and understand all instruction sheet information. Contact us for help, instructions, or repairs.
- ✔ Batteries should be replaced when the low battery indicator comes to prevent unreliable readings. If gauge is used infrequently, remove batteries to prevent damage from leaky batteries. Inspect batteries at least annually.
- ✓ Use specified power only. Improper voltages will damage the gauge. NEVER connect the gauge power wires directly to an electrical outlet or permanent damage will result.
- Gauges are not intended for permanent outdoor use. Protect from weather and excessive humidity. NEMA 4X models are available for temporary outdoor use and wash down areas.
- Install gauge so it is protected from impact damage.
- ✓ Media temperature and gauge ambient temperature must be within specified ranges.
- ✓ Use a screen or filter to avoid clogging gauge port when measuring contaminated media.
- ✓ Use thread sealant to ensure leak-free operation.
- ✓ Media being measured must be compatible with 316L SS.
- ✓ Avoid sensor damage! Sensor diaphragm is thin 316L SS foil. Never insert objects into the gauge port or blow out with compressed air.
- ✔ Avoid sensor damage! Hydraulic or liquid pumping systems must include a shock suppressor to protect gauge sensor from damaging pressure spikes or water hammer.
- ✔ Avoid sensor damage! Do not apply vacuum to nonvacuum gauges or hydraulic vacuum to any gauge.
- ♠ Do not exceed pressure range indicated on gauge label.
- ⚠ Remove system pressure before removing or installing gauge.

∆ Use fittings appropriate for the pressure range of the gauge.

△ Gauges are not for oxygen service. Accidental rupture of sensor diaphragm may cause silicone oil inside sensor to react with oxygen.

△ Only gauges marked as Intrinsically Safe can be used in hazardous locations or in the presence of flammable or explosive substances, or atmospheres.

Do not force housing! Use a wrench on hex fitting to install or remove.

Cecomp maintains a constant effort to upgrade and improve its products. Specifications are subject to change without notice. See cecomp.com for latest product information. Consult factory for your specific requirements.

Installation Tip

For food vacuum packaging applications an accumulation of debris may eventually clog the gauge port. A filter screen fitting should be installed to keep debris out of the gauge port. The screen fitting can be removed and cleaned as needed.



Description

Absolute reference gauges read zero at full vacuum and atmospheric pressure with the gauge port open.

With the gauge port open, it is normal for the reading to constantly change in response to atmospheric pressure changes.

The ARM760B and ARM760BBL models are designed for portable applications such as checking vacuum systems and packaging machinery.

The ARM760AD and ARM760ADBL models are designed for applications where a continuous display of vacuum is required such as monitoring vacuum systems and pumps.

Installation: ARM760AD, ARM760ADBL

The ARM760AD and ARM760ADBL models include 6 feet of cable with a female connector and a 120VAC/12VDC adapter with 6 feet of cable with plug.

After the gauge is installed, route the wires away from heat sources and moving equipment and connect the AC adapter's plug to the gauge cable connector. Lastly, plug the AC adapter into a 120 VAC outlet.

NEVER connect the gauge wires directly to 120 VAC or permanent damage not covered by warranty will result.

If you are using your own power source the ARM760AD and ARM760ADBL models can operate on any AC source of 8 to 24 VAC 50/60 Hz, or any DC source of 9 to 32 VDC. The type and magnitude of the supply voltage have negligible effects on the gauge calibration as long as it is within the voltage ranges stated above. No polarity needs to be observed when connecting a DC supply.

The only important consideration is to ensure that the gauge supply voltage does not fall below 8 VAC RMS if AC power is used, or 9 VDC if DC power is used. Operation with less than these values may cause erratic or erroneous readings.

If your application requires operation of several gauges from the same power supply, observe power requirements in

Operation: ARM760AD, ARM760ADBL

If the gauge display is off, press the center button to power

If the gauge was in the power-on state when the power was disconnected, the gauge will automatically turn on when power

If the gauge was turned off using the push button and then the power was turned off, the gauge will not power up until the power is reapplied and the center button is pressed again.

The gauge may be left on at all times or shut off when not

Display backlighting for BL models is on whenever the gauge is on. Backlighting may not be apparent under bright lighting conditions

Operation: ARM760B, ARM760BBL

Press the button on the front of the gauge to activate the

The gauge can be shut off at any time by pressing the button again.

The gauge will stay on for a period of time determined by the auto shutoff time

If the gauge was ordered without auto shutoff (-ON) it will stay on until the button is pressed or until the batteries are depleted. Display backlighting for BL models is on whenever the gauge is on. Backlighting may not be apparent under bright lighting conditions

Turn gauge off when not in use to conserve batteries.

Battery Replacement: ARM760B, ARM760BBL

A LOBAT low battery indication will be shown in the upper left corner of the display when the battery voltage falls sufficiently. The batteries should be replaced when the indicator comes to prevent unreliable readings.

Do not mix different batteries or fresh batteries with old. Replace both batteries with new ones at the same time.

- 1. Remove the 6 Phillips screws on the back of the gauge.
- 2. Remove battery holder if neccessary.
- 3. Remove batteries by lifting up the positive end of the battery (opposite the spring) taking care not to bend the spring.
- 4. Discard old batteries properly. See battery manufacturer's recommendations for disposal or recycling.
- 5. Install batteries with correct orientation, Insert the negative (flat) end of each battery first towards the battery holder
- 6. Replace the holder and back cover, including the rubber gasket.

Calibration Preparation

Gauges are factory calibrated at approximately 23°C using NIST traceable calibration equipment. Calibration is not required before using the gauge.

Calibration intervals depend on your quality standards, but annual re-calibration is customary. Calibration should be performed by qualified individuals using appropriate calibration standards and procedures.

Gauges can be returned to the factory for recalibration and repairs. NIST traceability is available.

The calibration equipment should be at least four times more accurate than the gauge being calibrated and be able to generate and measure pressure and/or vacuum over the full range of the gauge.

Calibration should only be attempted if the user has access to an absolute pressure reference of known accuracy that can generate and measure pressure/vacuum over the full range of the gauge.

Do not use a weather barometer for an atmospheric reference as they are normally offset to sea level based on altitude and thus do not read absolute atmospheric pressure.

A vacuum pump able to produce a vacuum of 100 microns (0.1 torr or 100 millitorr) or lower is required for zero calibration.

Install fresh batteries before calibrating battery-powered

Allow the gauge to equalize to normal room temperature for approximately 20 minutes before calibration.

For an as-found report, record readings at three to five points over the range of gauge.

Remove the black front potentiometer covers to access the zero and span calibration potentiometers.

Calibration

This procedure applies to all ARM760 models. The range is 760 torr (normal atmospheric pressure at sea level) to zero at full vacuum. Resolution is fixed at 1 torr.

Zero Calibration

Zero calibration must be done before span calibration.

Apply full vacuum to the gauge. Adjust the Zero potentiometer to match the gauge's display to your calibrator's absolute vacuum reading. It may be zero or close to it depending on the ability of the vacuum pump

Adjusting zero does not affect the span calibration.

Span Calibration

Set the pressure to obtain a calibrator reading of approximately 75% of full scale (570 Torr). This works well to minimize midrange non-linearity.

Adjust the Span potentiometer to match the gauge's display to your calibrator's reading.

Record readings at three to five points over the range of gauge and adjust span control to minimize error and meet specifications or for best accuracy over intended range of use.

Verification

Verify readings at 0%, 25%, 50%, 75%, and 100% of full scale. Replace the two front potentiometer covers.



ARM760B